







## Quick Setup Guide


### Buttons & basic commands



### Charging




### Pairing with other devices



To pair with your smartphone, press the "Up" and "Down" buttons simultaneously for 2 seconds until the light indicator flashes blue and red. The devices pair.


With CLEARLink app (free) you can do individual adjustments & updates.



To pair with Bluetooth headphones, turn off the device. Then press and hold the "On" button for 15 seconds. The light indicator first flashes purple, then blue. The devices pair.

When the device is switched off, it remembers the paired Bluetooth connections.




### Speaker



Insert USB plug of the cable headphones until the 3 ribs on the plug disappear completely into the USB socket.

### Connecting intercom devices



1. All devices should be turned off.
2. Turn on the first device by pressing the "On & Off" button and the "Down" button at the same time. The status indicator flashes purple.
3. On the second device, press the "On and Off" button and the "Up" button simultaneously for 5 seconds.
4. Repeat step 3 for all other devices immediately. If all devices are activated, continue to step 5.
5. All devices should now flash green and/or blue. To complete the pairing process, press the "On and Off" button once on the last device.
6. Turn off all devices to save the connection. The next time you activate them, the devices will recognize each other automatically (see "Activate / deactivate intercom").



### Activate / deactivate intercom

To reactivate intercom mode after the devices have been switched off or intercom has been deactivated, first activate the device(s). Then hold down the "Up" button on each device for 2 seconds. A signal tone sounds.


To deactivate intercom mode, press and hold the "Down" button on a device for 2 seconds.



### Private intercom group

If there is an intercom group, a private group can be set up. To do this, press the "On & Off" button and the "Up" button on the affected devices at the same time until the status display flashes purple. Then briefly press the "On & Off" button on the second device.

Briefly press the "On & Off" button to return to the entire group. The same applies to getting into private group.




### Reset

For full reset please press all three buttons at the same time for 2 sec.

### S.O.S. function U-SAFE




The devices have a manual S.O.S. Mode: The U-SAFE S.O.S. Mode allows the rider to manually trigger an emergency notification (after setting up U-SAFE in the CLEARLink app). When S.O.S is triggered, U-SAFE attempts to transmit the emergency notification immediately.



Tap the "On & Off" button 5 times, then again to activate S.O.S. to confirm. Without the 6th confirmation, S.O.S. will cancel sending the emergency notification.


It is also possible to store emergency contacts via the U-SAFE area in the CLEARLink app. More information in the app.

### Phone functions



Please make sure that your smartphone is connected to the device in advance. (s. a.).

### Music functions



Please make sure that your smartphone is connected to the device in advance. (s. a.).

Please read the complete operating instructions, which can be found at [www.usg-reitsport.de/downloads](http://www.usg-reitsport.de/downloads) or through the QR code shown here.



USG United Sportproducts Germany GmbH  
[www.usg-reitsport.de](http://www.usg-reitsport.de)



WEEE DE 76639754



Download  
CLEARLink

Android



iOS